



# ULTRADESK<sup>®</sup>


## HIGHLANDER





### • SCREW ACCESSORIES





### • PARTS ACCESSORIES





1





2




3




4




5




I\*2



6




J\*2






Please make sure the table legs are vertical to the connecting rod. And then tighten all the screws.

7




k



1. Please make sure the two boards are aligned and seamless.  
2. and then tighten the screws.

8




E




N



O



9



RESET

After the table is installed, please press the  key to start

During the reset process, the table will automatically run down to the lowest position for 5 seconds, and then the table will run up to a fixed position to stop.  
- successful installation